

Cordless Presenter for PowerPoint[®] – Quick Start Guide



Procedure (simple)

1. Turn on the computer
2. Switch on the Presenter
3. Launch PowerPoint
4. Press the **Launch slide show** button
5. Use the **Next** and **Previous** slide buttons to navigate through your presentation
6. Press the Laser Pointer button (only works in theatres with front projection)
7. Range is 15 metres (50 feet)
8. Ensure you turn off the Presenter when finished to conserve batteries

Advanced features

1. Set the timer to the amount of presentation time you have allocated. Use the **Timer set** button (hold to reset, increments in 5 minute steps)
2. Presenter will vibrate when 5 and 2 minutes remain. Display shows minutes remaining and a countdown bar

